Midi cable to XLR wiring diagram:

So - Pins 1 & 3 are not needed to send Midi - This means you can connect a midi port to any other kind of cable (TRS jack, xlr, bantam etc etc.) as your needs require.

For my purposes, I needed to create some MIDI to XLR's (see the accompanying blog on www.majetoneindustries.com

XLR

MIDI (5 PIN DIN)

POSITIVE

Pin 2 - Pin 5

NEGATIVE

Pin 3 - Pin 4

GROUND

Pin 1 - Pin 2

MAJETONE
INDUSTRIES